



Male Hormone (Serum) - KIT

Collection & Contents

Collection Requirements

None

Shipping Requirements

Sample Must Be Shipped Same Day— ONLY Ship samples: Monday— Thursday

Kit Contents

Contact Us if any items are damaged or missing

| Quantity | Item Description |
|----------|-----------------------------|
| 1 | Cold pack |
| 1 | Requisition form |
| 1 | Silver insulated envelope |
| 1 | Prepaid shipping label |
| 1 | Laboratory shipping pack |
| 2 | Serum separator tubes (SST) |
| 1 | Red top transfer tube |
| 1 | Transfer pipette |

Sample Stability

Refrigerate samples at 2—8 C° until shipment. We ask that samples are received within 1 day of collection. Do not freeze the samples.

Contact Us

9 Dunwoody Park, Dunwoody, GA 30338
(678) 736-6374 | info@precisionpointdiagnostics.com
www.precisionpointdiagnostics.com



Male Hormone (Serum) - KIT

Collection & Contents

Collection Requirements

None

Shipping Requirements

Sample Must Be Shipped Same Day— ONLY Ship samples: Monday— Thursday

Kit Contents

Contact Us if any items are damaged or missing

| Quantity | Item Description |
|----------|-----------------------------|
| 1 | Cold pack |
| 1 | Requisition form |
| 1 | Silver insulated envelope |
| 1 | Prepaid shipping label |
| 1 | Laboratory shipping pack |
| 2 | Serum separator tubes (SST) |
| 1 | Red top transfer tube |
| 1 | Transfer pipette |

Sample Stability

Refrigerate samples at 2—8 C° until shipment. We ask that samples are received within 1 day of collection. Do not freeze the samples.

Contact Us

9 Dunwoody Park, Dunwoody, GA 30338
(678) 736-6374 | info@precisionpointdiagnostics.com
www.precisionpointdiagnostics.com

Specimen Collection Instructions

1. Place cold pack in freezer for at least 4-6 hours minimum before shipping.
2. Collect the blood in the 2 SSTs.
3. Invert both SST tube gently 6 times, allow blood to clot between 30-45 minutes
4. Centrifuge ONE of the SST tubes
5. If gel barrier still has cells above gel, spin additional 5 minutes or transfer serum into transfer tube.
6. Transfer serum from the SST to Red top Serum Tube.
7. Using a permanent marker, write the patient's first and last name, date of birth, and date of collection on each sample tube.
8. Store the sample in a 2-8°C refrigerator until ready to ship. Do not freeze. Frozen samples will not be processed

Shipping Instructions

1. Make sure the specimen tubes are properly labeled.
Improperly labeled tubes cannot be processed.
2. Place the tube(s) inside of the biohazard bag and seal the bag. Do not remove gauze pad.
3. Complete the Test Requisition Form, fold and place the form within the outer pocket of the biohazard bag.
4. Place the biohazard bag into the silver insulated envelope.
5. Place the cold pack inside the silver insulated envelope.
6. Seal the envelope and place it inside the kit box.
7. Place the kit box inside the lab mailing pack.
8. Attach prepaid shipping label.
9. Take the package to the shipping carrier's storefront location or call the carrier to schedule a pickup.

Contact Us

9 Dunwoody Park, Dunwoody, GA 30338
(678) 736-6374 | info@precisionpointdiagnostics.com
www.precisionpointdiagnostics.com

Specimen Collection Instructions

1. Place cold pack in freezer for at least 4-6 hours minimum before shipping.
2. Collect the blood in the 2 SSTs.
3. Invert both SST tube gently 6 times, allow blood to clot between 30-45 minutes
4. Centrifuge ONE of the SST tubes
5. If gel barrier still has cells above gel, spin additional 5 minutes or transfer serum into transfer tube.
6. Transfer serum from the SST to Red top Serum Tube.
7. Using a permanent marker, write the patient's first and last name, date of birth, and date of collection on each sample tube.
8. Store the sample in a 2-8°C refrigerator until ready to ship. Do not freeze. Frozen samples will not be processed

Shipping Instructions

1. Make sure the specimen tubes are properly labeled.
Improperly labeled tubes cannot be processed.
2. Place the tube(s) inside of the biohazard bag and seal the bag. Do not remove gauze pad.
3. Complete the Test Requisition Form, fold and place the form within the outer pocket of the biohazard bag.
4. Place the biohazard bag into the silver insulated envelope.
5. Place the cold pack inside the silver insulated envelope.
6. Seal the envelope and place it inside the kit box.
7. Place the kit box inside the lab mailing pack.
8. Attach prepaid shipping label.
9. Take the package to the shipping carrier's storefront location or call the carrier to schedule a pickup.

Contact Us

9 Dunwoody Park, Dunwoody, GA 30338
(678) 736-6374 | info@precisionpointdiagnostics.com
www.precisionpointdiagnostics.com