



Advance Oxidative Stress (Whole Blood, Urine) - KIT

Collection & Contents

Collection Requirements

None

Shipping Requirements

ONLY Ship samples Monday— Thursday

Kit Contents

Contact Us if any items are damaged or missing

Quantity	Item Description	Quantity	Item Description
1	Cold pack	1	Urine collection cup
1	Requisition form		
1	Biohazard bag with gauze pad		
1	Silver insulated envelope		
1	Prepaid shipping label		
1	Laboratory shipping pack		
1	Lavender top EDTA tube		
1	Transfer pipette		
1	Yellow tube 5mL transfer tube		

Sample Stability

Refrigerate samples at 2—8 C° until shipment. We ask that samples are received within 5 days of collection. Do not freeze the samples.

Contact Us

9 Dunwoody Park, Dunwoody, GA 30338
(678) 736-6374 | info@precisionpointdiagnostics.com
www.precisionpointdiagnostics.com



Advance Oxidative Stress (Whole Blood, Urine) - KIT

Collection & Contents

Collection Requirements

None

Shipping Requirements

ONLY Ship samples Monday— Thursday

Kit Contents

Contact Us if any items are damaged or missing

Quantity	Item Description	Quantity	Item Description
1	Cold pack	1	Urine collection cup
1	Requisition form		
1	Biohazard bag with gauze pad		
1	Silver insulated envelope		
1	Prepaid shipping label		
1	Laboratory shipping pack		
1	Lavender top EDTA tube		
1	Transfer pipette		
1	Yellow tube 5mL transfer tube		

Sample Stability

Refrigerate samples at 2—8 C° until shipment. We ask that samples are received within 5 days of collection. Do not freeze the samples.

Contact Us

9 Dunwoody Park, Dunwoody, GA 30338
(678) 736-6374 | info@precisionpointdiagnostics.com
www.precisionpointdiagnostics.com

Specimen Collection Instructions

Blood:

1. Place cold pack in freezer for at least 4-6 hours minimum before shipping.
2. Collect the blood in the Lavender EDTA tube provided, gently invert 8 times.
3. Using a permanent marker, write the patients first and last name, date of birth, and date of collection on each sample tube.
4. Store the sample in a 2-8°C refrigerator until ready to ship. Do not freeze. Frozen samples will not be processed.

Urine:

1. Collect urine at any time of day in the urine collection cup.
2. Using the transfer pipette, transfer 5mL of urine into the Yellow Top transfer tube.
3. Using a permanent marker, write the patients first and last name, date of birth, and date of collection on each sample tube.
4. Store urine in freezer until shipping.

Shipping Instructions

1. Make sure the specimen tubes are properly labeled.

Improperly labeled tubes cannot be processed.

2. Place the tube(s) inside of the biohazard bag and seal the bag. Do not remove gauze pad.
3. Complete the Test Requisition Form, fold and place the form within the outer pocket of the biohazard bag.
4. Place the biohazard bag into the insulated shipping envelope.
5. Place the cold pack inside the silver insulated envelope.
6. Seal the envelope and place it inside the kit box.
7. Place the kit box inside the lab mailing pack.
8. Attach prepaid shipping label.
9. Take the package to the shipping carrier's storefront location or call the carrier to schedule a pickup.

Contact Us

9 Dunwoody Park, Dunwoody, GA 30338
(678) 736-6374 | info@precisionpointdiagnostics.com
www.precisionpointdiagnostics.com

Specimen Collection Instructions

Blood:

1. Place cold pack in freezer for at least 4-6 hours minimum before shipping.
2. Collect the blood in the Lavender EDTA tube provided, gently invert 8 times.
3. Using a permanent marker, write the patients first and last name, date of birth, and date of collection on each sample tube.
4. Store the sample in a 2-8°C refrigerator until ready to ship. Do not freeze. Frozen samples will not be processed.

Urine:

1. Collect urine at any time of day in the urine collection cup.
2. Using the transfer pipette, transfer 5mL of urine into the Yellow Top transfer tube.
3. Using a permanent marker, write the patients first and last name, date of birth, and date of collection on each sample tube.
4. Store urine in freezer until shipping.

Shipping Instructions

1. Make sure the specimen tubes are properly labeled.

Improperly labeled tubes cannot be processed.

2. Place the tube(s) inside of the biohazard bag and seal the bag. Do not remove gauze pad.
3. Complete the Test Requisition Form, fold and place the form within the outer pocket of the biohazard bag.
4. Place the biohazard bag into the insulated shipping envelope.
5. Place the cold pack inside the silver insulated envelope.
6. Seal the envelope and place it inside the kit box.
7. Place the kit box inside the lab mailing pack.
8. Attach prepaid shipping label.
9. Take the package to the shipping carrier's storefront location or call the carrier to schedule a pickup.

Contact Us

9 Dunwoody Park, Dunwoody, GA 30338
(678) 736-6374 | info@precisionpointdiagnostics.com
www.precisionpointdiagnostics.com